


## Gunite Automatic Slack Adjuster Identification


With the launch of Gunite’s new state-of-the-art automatic slack adjuster assembly line there has been a change to the identification information formatting. The identification information now includes the part number, date code and serial number (TYPE II). The identification information is located on the end cap facing the brake chamber. Please reference the below illustrations for the identification information and formatting.

### Automatic Slack Adjuster Data Code Illustration

#### Type I



#### Type II



Please continue to supply the part number and date code information on all warranty claims as has been done in the past. For further information, contact Gunite Field Engineering at (800) 677-3786.

